





Configuração do leitor de código de barras Datalogic para código de barras 2 of 5 i

1	 ENTER/EXIT PROGRAMMING MODE	7	 ENTER/EXIT PROGRAMMING MODE
2	 I 2 of 5 = Enable	8	 Set I 2 of 5 Length 1
3	 ENTER/EXIT PROGRAMMING MODE	9	 0
4	 ENTER/EXIT PROGRAMMING MODE	10	 4
5	 2 of 5 Length Control = Fixed Leng	11	 ENTER/EXIT PROGRAMMING MODE
6	 ENTER/EXIT PROGRAMMING MODE		
Teste			 0729